



NOTES FOR FIELD INSTALLATION – POLYETHYLENE WRAP:

STEP-1

PLACE THE TUBE OF POLYETHYLENE MATERIAL AROUND THE PIPE PRIOR TO LOWERING IT INTO THE TRENCH.

STEP-2

PULL THE TUBE OVER THE LENGTH OF THE PIPE. TAPE THE TUBE TO THE PIPE AT THE JOINT. FOLD MATERIAL AROUND THE ADJACENT SPIGOT END AND WRAP WITH THREE CIRCUMFERENTIAL TURNS OF 2-INCH WIDE PLASTIC TAPE TO HOLD PLASTIC TUBE AROUND SPIGOT END.

STEP-3

ADJACENT TUBE OVERLAPS FIRST TUBE AND IS SECURED WITH PLASTIC ADHESIVE TAPE. THE POLYETHYLENE TUBE MATERIAL COVERING THE PIPE WILL BE LOOSE. EXCESS MATERIAL SHALL BE NEATLY DRAWN UP AROUND THE PIPE BARREL, FOLDED INTO AN OVERLAP ON TOP OF THE PIPE, AND HELD IN PLACE BY MEANS OF PIECES OF PLASTIC TAPE AT APPROXIMATELY 3-FOOT INTERVALS.

NOTE:

AT LOCATION OF TAP, APPLY THREE OR FOUR WRAPS OF PLASTIC TAPE COMPLETELY AROUND THE PIPE FOR A WIDTH THAT WILL PROVIDE PROTECTION OF THE POLYETHYLENE WRAP FROM THE TAPING MACHINE.

CORP STOP

D DENVER WATER	
POLYETHYLENE WRAP ON PIPE & AT TAP INSTALLATION	
Scale: <u> NONE </u>	Date: <u> May 2018 </u>
Drawn: <u> RLB </u>	Ck: <u> K ROSS </u>
Approved: <u> Steph C. P... </u>	Dr. <u> 127 </u> No. <u> 35 </u>